This section covers the more-common problems that motorists experience with their vehicles. It gives you information about how to safely evaluate the problem and what to do to correct it. If the problem has stranded you on the side of the road, you may be able to get going again. If not, you will also find instructions on getting your car towed.

Compact Spare Tire..... 270
Changing a Flat Tire..... 271
If Your Engine Won't Start..... 276
Nothing Happens or the Starter Motor Operates Very Slowly..... 277
The Starter Operates Normally..... 278
Jump Starting..... 278
If Your Engine Overheats..... 281
Low Oil Pressure Indicator..... 283
Charging System Indicator..... 284
Malfunction Indicator Lamp 285
Brake System Indicator..... 286
Closing the Moonroof..... 287
Fuses..... 288
Checking and Replacing..... 289
Emergency Towing..... 293